



SPEED REDUCTION GEARBOX

BENTLEY LEADSCREW DISCONNECT

GEARBOX
OUTPUT
SHAFT

CLUTCH DOG

CLUTCH BODY

EXISTING LATHE BED

RETAINER

FORK

CLUTCH OUTPUT SHAFT

ACTUATOR
BALL HANDLE

SLIDING PLATE

COVER PLATE

END CAP / BEARING

LEADSCREW

SPLIT PIN